

Introduction

The oscilloscope has been an indispensable tool in research and design for decades, enabling a steady stream of innovations in countless industries. One of the key specifications of an oscilloscope is record length. Record length is the number of samples an oscilloscope can digitize and store in a single acquisition. The longer the record length, the longer the time window the oscilloscope can capture with high timing resolution (high sample rate). The first digital oscilloscopes could capture and store only 500 points which made it very difficult to acquire all relevant information around the event being investigated. Designers were constantly faced with a choice of either acquiring a



Application Note

longer period of time at low resolution or a shorter period of time at high resolution, when what they really wanted was both: a long capture window and high resolution. As time went by and technology progressed, the speed, ease, and cost of digitizing more detail became more favorable. However, at the same time, clock speeds rose, bus topologies evolved through both wider and faster parallel designs as well as a shift towards serial buses, and overall system design complexity skyrocketed. Due to this, designers' demands for longer capture windows with high resolution continued to rise as fast, or even faster, than oscilloscope manufacturers' ability to increase record length. There will be no let-up in this trend. Moore's Law continues to push electronic technology faster, system designs continue to become more complex, and subsequently harder to design, build, troubleshoot, and fix when they break. So what does this mean to modern oscilloscopes? As designs become faster and more complex, the need for long records, more bandwidth, and higher sampling rate, will also increase. The relationship between these key specifications is not very complex. As bandwidth goes up, the sampling rate must be approximately five times higher to accurately capture the signal's high frequency content. As the sampling rate goes up, a given time window of signal acquisition requires more samples. For example: to capture 2 milliseconds of a 100 MHz signal at 5 GS/s requires a 10 million point record. (Divide 2 milliseconds by the 200 picosecond sample interval.) Even at lower frequencies there are many applications that require long records. Just capturing a single frame of NTSC video (two fields in a

1/30th of a second interval, at 100 MS/s to resolve all the luminance information) requires over 3 million points (33 milliseconds divided by 10 nanoseconds). Capturing several seconds of bus traffic on a 1Mb/s CAN bus to diagnose problems in an electro-mechanical system may require 10 million points for adequate resolution. These and a variety of other applications have driven and continue to drive the need for longer and more detailed data capture windows.

Analyzing all that Data

As stated earlier, the first digital oscilloscopes had very short record length. As such, it was easy to see everything the oscilloscope captured because it was all on the screen at one time. As records got longer, horizontal scrolling was used to see all the data. This was not a big issue as you move from one screen's worth of information to two, then up to four, eight, twenty, etc. However, as records became longer and longer with each generation of oscilloscope, the time required to look through all the data captured in a single acquisition grew longer and longer. We are now dealing with record lengths in the millions of points that represent thousands of screens worth of signal activity. By way of comparison, imagine trying to find what you're looking for on the Internet without the assistance of your favorite search engine, web browser, or bookmarks. It would be like searching for a needle in a haystack. Until now, this is what oscilloscope users have faced with their long record length oscilloscopes. Clearly, the old solutions will no longer work.



Figure 1. 4000 Series Wave Inspector® provides dedicated front panel controls for efficient waveform analysis.

Wave Inspector®

The Tektronix 4000 Series oscilloscope Wave Inspector controls make working with long records and extracting the answers you need from your waveforms a simple and efficient process.

Zoom / Pan

Most digital oscilloscopes on the market today offer some form of zoom capability. However, the controls associated with the zoom view (zoom factor and position) are often buried in menus or multiplexed with other front panel controls. For example, the zoom window's horizontal position is typically controlled by the horizontal position knob on the front panel. Once you've zoomed in on an event of interest, if you want to move the zoom window to another location in the acquisition it typically means either turning the horizontal position knob countless times to slowly move the window to the new location, or zooming back out, adjusting the window's location and then zooming back in. Neither approach is efficient or intuitive. It becomes even less efficient when you have to navigate through menus just to access these basic zoom controls.

Application Note

As shown in Figure 1A, Wave Inspector provides a dedicated two-tier front panel Zoom / Pan knob for efficient waveform navigation. The inner knob controls the zoom factor. The farther clockwise you turn it, the farther you zoom in. Turning it counter-clockwise zooms back out and ultimately turns zoom off.

The outer ring is a force/rate sensitive pan control. Turning it clockwise pans the zoom window right on the waveform, counterclockwise pans it left. The farther you turn it, the faster the zoom window moves across the waveform. In Figure 2, we can quickly navigate from one packet to the next by simply turning the pan control in the desired direction. Even with a 10 million point aquisition, you can rapidly move the zoom window from one end of the record to the other in a few seconds, without ever having to change your zoom factor.

In Figure 2 we're probing an I²C bus. The complete acquisition is shown in the upper window and the zoomed portion is in the lower, larger window. In this case we've zoomed in to view the decoded address and data values for one particular packet.



Figure 1A. Wave Inspector® provides dedicated front panel zoom and pan controls.

Application Note



Figure 2. Navigating through a long acquisition of an I²C bus.

Application Note

Play / Pause

Many times when debugging a problem, you don't know what's causing the problem so you're not sure what to look for in the waveform you've acquired. However, you know you've captured the time window that contained the problem and you now need to look through the data you've captured to see if you can find the issue. Again, on most modern oscilloscopes this is done by manually turning the horizontal position knob countless times to inspect the acquired waveforms for any suspicious activity. Wave Inspector helps in this area as well. You can simply press the Play button on the front panel to have your zoom window automatically pan across the waveform. Play speed and direction are adjusted using the intuitive pan control. The farther you turn the pan control the faster the waveform plays by. This allows hands-free playback so you can concentrate on what's important - the waveform itself. In the I²C example (Figure 2), you could play the waveform while watching the decoded address and data values to monitor activity on the bus. When you spot the event you're looking for simply press the Play/Pause button again to stop the waveform.



Application Note

Marks

While looking for the source of the problem, you may find numerous areas of the waveform that either warrant further investigation or are indicative of something happening in the device under test that you want to use as a reference point during the rest of your analysis. For example, assume you need to make timing measurements associated with the latency from when a driver presses the Passenger Window Down switch on the driver's door panel to when the passenger window actually starts to move. The first event you'll want to find in the acquisition is when the switch was pressed. The next may be when the CAN module in the driver's side door issues the command to the CAN module in the passenger door. The last event may be when the motor engaged in the passenger door and the window started to move. Wouldn't it be nice to mark each of these locations on the waveform so you can quickly jump back and forth between the areas of interest for timing measurements? With the Tektronix 4000 Series you can.

In Figure 3, Channel 1 is the output of the switch in the driver's door, channel 2 is the CANbus, and Channel 3 is monitoring the motor drive in the passenger door.



Application Note



Figure 3. Placing marks on the waveform to assist in latency measurements on a CAN bus.

We've set the oscilloscope up to trigger on the packet of interest by specifying the appropriate Identifier and Data. Next, we've used the front panel Set / Clear Mark button to mark each of the events of interest on the waveform. These user marks are shown as solid white triangles along the top edge in both the upper and lower windows. The rising edge on channel 1 indicates when the switch was pressed. The trigger event is the CAN module in the driver's door issuing the command and the window beginning to move is the transition on Channel 3. Using the front panel Previous and Next buttons we can instantly jump between marks to place cursors for quick and easy latency measurements. In Figure 3, we find that the total time from the press of the switch to window movement is 58.8ms, well within the amount of acceptable delay.

Search Function

Application Note

Search & Mark

In addition to placing marks on waveforms manually, Wave Inspector has the power to search through the entire acquisition and automatically mark every occurrence of a user specified event. For example, imagine you are capturing laser pulses. The laser fires approximately every 20 μ s, with each pulse being only 15 ns wide. You want to look at multiple pulses to characterize their shape and to make precise timing measurements between them, but to navigate from one to the next you need to sift through close to 20 μ s of dead time. Then you need to repeat this for every other pulse in the acquisition. Clearly, it would be desirable to be able to move from pulse to pulse instantly without having to waste time "twiddling" a position knob.



Figure 3A. Wave Inspector's[®] powerful Search capability allows you to find every occurrence of a user specified event in the acquisition.

Application Note



Figure 4. 4000 Series marking every pulse that crosses 300mV in a long acquisition.

A very simple search setup that looks for rising edges that cross a threshold of 300mV is illustrated in Figure 4. Marks generated by the search are shown as hollow white triangles along the top edge in both the upper and lower windows. This search resulted in 105 marks being placed throughout the record. Now all you have to do is press the front panel previous and next buttons to jump from one pulse to the next, no adjustment of zoom scale or position is required!

Application Note



Figure 5. Setup & Hold violation search results in six occurrences found.

Wave Inspector's search feature goes well beyond simple edge searches though. Imagine the chip you're working with has an indeterminate output every so often that's causing the overall system to crash. You suspect that it's a metastability issue caused by Setup & Hold violations. In a matter of seconds, you can specify search criteria to have the oscilloscope automatically find every occurrence in the acquisition where setup and hold times you specify were violated. In this case, the part we're using has published setup and hold times of 12 ns and 6 ns, respectively. To have the oscilloscope automatically find violations of these limits, we simply need to tell it clock is on Channel 1, Data is on Channel 2, set the thresholds, and enter the desired setup and hold times. The oscilloscope then checks the timing relative to every clock edge throughout the entire acquisition Application Note

and marks the occurrences that violate the specified setup and hold times. In Figure 5, our search resulted in six violations. The six events are marked with hollow white triangles in the upper window. The lower window is showing a zoomed in view of one of the violations. It's clear that the narrow negative pulse on the data line is violating the 12 ns setup time.

We've found the metastability source without having to manually scroll through the waveform and without having to use cursors to measure anything. You can even perform worst case checks by adjusting the setup and hold times and seeing how many events Wave Inspector finds. For example, you can set the hold time to zero and then reduce the setup time until only one event is found. Note: The MSO4000 Series oscilloscopes can search for setup & hold violations on every channel in the oscilloscope. DPO4000 Series oscilloscopes can only search for violations on one channel at a time.

Another powerful search capability provided by Wave Inspector is searching for data in a bus. You can use the front panel bus buttons to define your signals as an I²C, SPI, CAN, RS-232, or parallel bus. Then the oscilloscope will decode the bus into packets, displaying the information in a meaningful form. You can trigger on or search for data in the packets. (I²C and SPI require the optional DPO4EMBD application module. CAN requires DPO4AUTO. RS-232 requires DPO4COMP. Parallel requires an MSO4000 Series oscilloscope.)

Application Note



Figure 6. Searching for specific Identifier and Data values in CAN messages.

While this triggering is critical to isolate the time window that contains the problem, it's highly likely that you'll need to view bus activity over many packets to understand what's going on at a system level. The bus search feature enables you to specify packet level criteria and mark every occurrence of it in the record for quick viewing, navigation and analysis. Continuing the earlier CAN example, in Figure 6 we've searched for every message in a long acquisition of a CAN bus with the specific Identifier (549) and Data (A1) values we're interested in.

Application Note

Search Type	Description
Edge	Searches for edges (rising or falling) with a user specified threshold level.
Pulse Width	Searches for positive or negative pulse widths that are >, <, =, or \neq a user specified pulse width.
Runt	Searches for positive or negative pulses that cross one amplitude threshold but fail to cross a second threshold before crossing the first again. Search for all runt pulses or only those with duration >, <, =, or \neq a user specified time.
Logic	Search for a logic pattern (AND, OR, NAND, or NOR) across multiple waveforms with each input set to either High, Low, or Don't Care. Search for when the event goes true, goes false or stays valid for >, <, =, or \neq a user specified time. Additionally, you can define one of the inputs as clock for synchronous (state) searches.
Setup & Hold	Search for violations of user specified Setup and Hold times.
Rise / Fall Time	Search for rising and/or falling edges that are >, <, =, or \neq a user specified time.
Bus	l ² C: Search for Start, Repeated Start, Stop, Missing Ack, Address, Data or Address & Data. SPI: Search for SS Active, MOSI, MISO, or MOSI & MISO. CAN: Search for Start of Frame, Type of Frame (Data, Remote, Error, Overload), Identifier (standard or extended), Data, Identifier & Data, End of Frame, or Missing Ack. RS-232: Search for Tx start bit, Tx end of packet, Tx data, Rx start bit, Rx end of packet, Rx data. Parallel: Search for data value.

Table 1. Search events.

Wave Inspector found four messages in the acquisition that met the criteria. Again, moving the zoom window from one occurrence to the next is as simple as pressing the previous and next buttons on the front panel. And because the oscilloscope is decoding the packets for you, you can instantly see all the relevant information without having to manually decode from analog waveforms.

In addition to the examples provided above, the Tektronix 4000 Series can search for many other types of events. The full list of search capabilities is shown in Table 1.

Wave Inspector[®] Simplifying Waveform Analysis Application Note

Multiple Searches

An obvious question at this point is, "What if I want to perform another search, but don't want to lose the results (marks) from my first search?" Simply select the Save All Marks menu selection and you'll see that the hollow white triangle search marks become filled in, appearing the same as marks placed with the front panel Set Mark button. These marks are now saved on the waveform and a new search can be performed. You can do this as many times as you like, effectively creating unlimited searching ability. Of course, if you would like to start over with a clean slate you can press the Clear All Marks button to remove all marks from the waveform or you can remove any single mark using the Set/Clear Mark front panel button.

Search Interaction with Trigger

Two other powerful and time-saving capabilities are included in the Search menu: the ability to copy trigger settings to search and copy search settings to trigger. Copying the current trigger settings to the search menu is most useful when you want to search through the acquisition to see if there are any other occurrences of the trigger event in the captured data. Alternatively, copying search settings to the trigger menu is most useful when you've found an event in your data and you want to reacquire new data using that event as the trigger criteria.



Figure 7. Search side menu.

Conclusion

Modern digital oscilloscopes can capture massive amounts of data. This can be both a blessing and a curse. You want all that data, that's why you need the oscilloscope. But until now, finding the needle that is important in the haystack of data has been an exceptionally time-consuming and frustrating process. The Tektronix 4000 Series with Wave Inspector gives you the tools to extract the answers you need with efficiency you wouldn't have dreamed possible with an oscilloscope.

Contact Tektronix:

ASEAN / Australasia (65) 6356 3900 Austria +41 52 675 3777 Balkan, Israel, South Africa and other ISE Countries +41 52 675 3777 Belgium 07 81 60166 Brazil & South America (11) 40669400 Canada 1 (800) 661-5625 Central East Europe, Ukraine and the Baltics +41 52 675 3777 Central Europe & Greece +41 52 675 3777 Denmark +45 80 88 1401 Finland +41 52 675 3777 France +33 (0) 1 69 86 81 81 Germany +49 (221) 94 77 400 Hong Kong (852) 2585-6688 India (91) 80-22275577 Italy +39 (02) 25086 1 Japan 81 (3) 6714-3010 Luxembourg +44 (0) 1344 392400 Mexico, Central America & Caribbean 52 (55) 5424700 Middle East, Asia and North Africa +41 52 675 3777 The Netherlands 090 02 021797 Norway 800 16098 People's Republic of China 86 (10) 6235 1230 Poland +41 52 675 3777 Portugal 80 08 12370 Republic of Korea 82 (2) 528-5299 Russia & CIS +7 (495) 7484900 South Africa +27 11 254 8360 Spain (+34) 901 988 054 Sweden 020 08 80371 Switzerland +41 52 675 3777 Taiwan 886 (2) 2722-9622 United Kingdom & Eire +44 (0) 1344 392400 **USA** 1 (800) 426-2200 For other areas contact Tektronix, Inc. at: 1 (503) 627-7111 Updated 15 September 2006

For Further Information

Tektronix maintains a comprehensive, constantly expanding collection of application notes, technical briefs and other resources to help engineers working on the cutting edge of technology. Please visit **www.tektronix.com**

- F

Copyright © 2005, Tektronix, Inc. All rights reserved. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX and TEK are registered trademarks of Tektronix, Inc. All other trade names referenced are the service marks, trademarks or registered trademarks of their respective companies.

12/05 FLG/WWW

48W-19039-2

